

Drill Press:

1. Are you wearing safety glasses?
2. Tie back long hair, (shoulder length or longer), loose clothing, etc.
3. Clamp work piece to table.
4. Check chuck for tightness on bit.
5. Remove chuck key from spindle.
6. Tighten table lock to column.
7. Turn on work light.
8. Clear work area of others before turning on drill press motor.
9. **Warning: Never reach into work piece while drill is running.**
10. Please: Replace the bit after use!

Disk Sander

1. Are you wearing safety glasses?
2. Tie back long hair, (shoulder length or longer), loose clothing, etc.
3. Check table for squareness to disk.
4. Check gap between table and disk.
5. Do not sand any flat work piece less than 1/8" thick on this sander.
6. Clear work area of others before turning on disk sander motor.
7. Warning: Never brush off table while disk is turning.
8. Always work on left side of disk.

Vertical Band Saw:

1. Are you wearing safety glasses?
2. Tie back long hair, (shoulder length or longer), loose clothing, etc.
3. Ensure blade is correct for material.
4. Set blade guide / guard to within .10" of top of work piece.
5. Check blade guide / guard is locked.
6. Clear work area of others before turning on band saw motor.
7. **Warning: Never place hands / fingers in path of blade.**
8. **Use push blocks!**

Table Saw:

1. Are you wearing safety glasses?
2. Tie back long hair, (shoulder length or longer), loose clothing, etc.
3. Check blade height and angle.
4. Lock blade carriage.
5. Use fence or cross feed appropriately.
6. Clear work area of others before turning on table saw motor.
7. **Warning: Never reach into work piece while saw is running!**
8. Please: Place blade to vertical, and cross feed to perpendicular after use!